

H.N.T. Gordon Product - Use and Care Instructions

Planing Flat Boards

Using the smoothing plane is best achieved by standing directly behind the work piece pushing squarely from the shoulders as shown. You should be able to plane up to 3 feet long boards in this manner.



Using the Trying planes on long boards, over 3 feet, you can slightly skew the plane body and walk beside the work piece using the recommended hand grip as shown.

Guarantee: Unconditional guarantee on workmanship and materials.

Copyright ©2006 H.N.T. Gordon - Used with permission

PDF Produced by Craftsman Studio - 888-500-9093 - <http://CraftsmanStudio.com>